

3in1 Breakfast maker



Using Your Toaster Oven

Please familiarize yourself with the following oven functions and accessories prior to first use:

Coffee power switch: turn on coffee maker .

Thermostat Knob: Set desired cooking temperature from (100°C to 230°C).

Timer Knob: Turn the knob counter-clockwise to the STAY ON position and the oven will operate continuously until manually shut off. To activate the timer, turn the knob clockwise to set the cooking time. A bell will sound at end of programmed time.

Indicator light: It is illuminated whenever the oven is turned on.

Grill Rack, Baking Tray: For toasting, baking, and general cooking.

Frying pan: For frying ,toasting, baking, and general cooking.

Toasting ,frying and coffee maker can be using in same time .

Operation

Important: This oven gets hot. When in use, always use oven mitts or similar when touching an outer or inner surface of the oven.

Grill

This oven is designed to provide a grill function with the door slightly ajar.

For best results, preheat oven with door closed at 230°C for at least 8 minutes before grilling.

1. Insert the Food Tray into the rack and position the Grill Rack into the top rack slot in the oven. 2.Turn the Thermostat Knob to the desired temperature setting from 100°C to 230°C. 3.Turn on the Timer Knob past 20 and then turn back or forward to desired baking time, including 8 minutes preheat time. 4.If you are not using the timer you must turn the Timer Knob (counter-clockwise) to the STAY ON mode, However, average grilling time is normally under 20 minutes. So use of the timer and constant supervision is highly recommended. 5.Once oven had preheated, open the glass door and place food to be cooked on Grill Rack.
- 6.Close the glass door but leaving it ajar about 3cm from the fully closed position. 7. If using the timer, there will be an audible signal (bell) once the grilling cycle is complete. 8.If not using the timer, turn the Timer Knob to OFF position once cooking cycle is done.

- 9.Watch food carefully and check it to see if it is done. 10. If using the timer, the oven turns OFF and the indicator goes out after the designated amount of time. 11. When grilling is finished, turn the Thermostat Knob to the OFF position and using oven mitt

Frying For best results, preheat oven for 8 to 10 minutes at desired frying temperature before

1. Clean the frying pan ,put some oil on it and place on correct position, 2. Turn the Thermostat Knob to the desired temperature setting from 100°C to 230°C.3.Turn the Timer Knob past 30 and then turn back or forward to desired baking time, including preheat time.