# User Manual for the Electric lunch box

I. Usage Instructions

Fill the inner pot to two-thirds full with water

2. Cover the lid after placing the food inside

3. Press the heating button

II. Precautions

1. Do not run empty to avoid damage

2. To avoid burns, do not touch the outer surface

3. For heating food only; do not boil water

III. Feature Introduction

1. Rapid heating to maintain food temperature

2. Multi-layer design, suitable for household use

IV. Common Issues

1. No heating: Check if the power supply is sufficient

2. Low water level: Add water to the marked line