Cotton Candy Maker User Manual

I. Product Usage Instructions

1. **Correct Usage**

Place the cotton candy maker on a flat, stable, dry and heat-resistant surface. Keep a safe distance from walls, curtains and flammable materials. Connect the unit to the rated power supply securely.

Check that the spinning head and sugar tray are installed firmly. Turn on the power and heating switch, preheat the machine for 2 to 3 minutes. Add an appropriate amount of granulated sugar or special colored sugar into the center of the spinning head.

After the sugar filaments come out, slowly rotate a paper stick along the inner wall of the tray to wind cotton candy evenly. Do not put excessive sugar at one time to avoid machine jamming or overheating.

During operation, do not put hands or foreign objects close to the high-temperature spinning head and rotating parts to prevent scalds and injuries. Do not shake or move the machine while working.

After use, turn off the heating switch first, then cut off the power and unplug the cord. Wait for the machine to cool down completely before cleaning, moving or storage.

1. **Pre-use Preparation**

Before first use, wipe and clean the sugar tray, spinning head and inner cavity with a soft cloth. Wash detachable parts with warm water and neutral detergent, then dry thoroughly.

Inspect the power cord, plug and machine body for damage. Confirm the spinning head rotates smoothly and the heating component works normally.

Run empty preheating for a few minutes to remove factory odor, then cool down before formal production to ensure hygiene and safe use.

1. **Usage Restrictions**

For household use only, not suitable for long-term commercial continuous operation.

Only use edible white granulated sugar or dedicated cotton candy sugar. Do not add hard candy, impurities or non-edible materials.

Do not operate the machine without sugar for dry heating. Continuous working time shall not exceed 30 minutes; stop and cool down regularly to protect the motor and heating elements.

Do not block heat dissipation vents. Do not immerse the main body, power cord and plug in water to avoid electric shock and damage.

1. **Model Information**

This product is a **Good Luck Horse** brand cotton candy maker.

Product model, rated voltage, power and related parameters are clearly marked on the nameplate.

II. Compliance Marks

CE mark certification symbol (see product label).

EC REP: evat master Consulting GmbH, Germany

Address: Bettinastr.30, 60325 Frankfurt am Main, Germany

Contact: 49-6995179070 | contact@evatmaster.com

III. Applicable Regulations and Standards

Complies with **GB 4706.1-2005** Safety of Household and Similar Electrical Appliances — Part 1: General Requirements

and **GB 4706.19-2008** Particular requirements for electric cooking appliances.

IV. Warnings/Safety Information

⚠ **Warning**: Read the manual carefully to avoid electric shock, scalding and fire hazards.

⚠ **Warning**: Keep the machine away from children. Do not allow children to operate or touch high-temperature and rotating parts.

⚠ **Warning**: Do not touch the power plug with wet hands. Do not disassemble or modify the product privately.

⚠ **DANGER**: Stop using immediately if the power cord, heating element or rotating part is damaged.

⚠ **DANGER**: If abnormal noise, burning smell, smoke or overheating occurs, cut off power supply in time and contact after-sales service.