1. Introduction
Thank you for choosing our product. Please read this manual carefully before first use for safe operation, and keep it for future reference. Our product is des igned for reliability and convenience.

2. Safety Precautions
- Do not use the product beyond its intended purpose to avoid damage or injur y.
- Keep away from children under 3 years old without supervision; small parts may cause choking (if applicable).
- Stop using immediately if the product is damaged, malfunctioning or makes abnormal noises; contact customer service.
- Do not disassemble, modify or repair the product yourself (may void warrant y and cause risks).
- For electrical products: Match voltage before use; keep away from water/hea t; unplug when not in use; replace damaged cords/plugs with originals only.
- Avoid extreme temperatures, direct sunlight and heavy loads on the product.

3. How to Use
- Unpack and check all parts; contact customer service if missing/damaged.
- Clean the product surface with a soft, dry cloth (no corrosive cleaners).
- Power on: Press "ON/OFF" button; adjust settings (if applicable) as needed.
- Use as intended; avoid overuse or improper operation.
- Power off: Press "ON/OFF" again; unplug electrical products after use.

4. Maintenance
- Turn off/unplug before cleaning; wipe dry if using mild cleaners.
- Do not immerse in water unless marked waterproof.
- Check accessories regularly; replace damaged parts with originals only.
- Charge batteries regularly (if applicable); do not overcharge/over-discharge.