XIAOMI MIJIA Dust Mite Vacuum Cleaner 2 Pro User Manual

Safety Instructions

Read this manual carefully before use, and retain it for future reference.

WARNINGS

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a way that they understand the hazards involved. Children shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard.
- The plug must be removed from the socket-outlet before cleaning or maintenance.
- The dust mite vacuum cleaner contains with ± 10 light. Do not expose the eyes or skin of people or pets to the light for a long time, or it may cause eye or skin injury.
- When cleaning the UV light, make sure the dust mite vacuum cleaner is powered off and the UV light is turned off. Do not touch the UV light with your hands, or it may cause burns. Only qualified and trained maintenance personnel are allowed to replace the UV light.
- Do not use the dust mite vacuum cleaner to pick up any flammable or explosive substances such as kerosene, gasoline, and solvent, or use it in a flammable or explosive environment, such as a place where there is a risk of fire or explosion, such as gas, dust, fibers, airborne, and dust cleaner.
- Do not use the dust mite vacuum cleaner to vacuum strained particles, ignite the fireplace ash, or smoking or burning cigarettes or other flammable objects.
- Do not use the dust mite vacuum cleaner to pick up hard or sharp objects such as glass, nails, screws, or coins, which may damage the product.
- Do not place the dust mite vacuum cleaner in a place with high temperature and direct sunlight to prevent the product from deformation and damage. Do not place the dust mite vacuum cleaner in a place with a high humidity to prevent the product from rusting.
- WARNING: The appliance contains a UV emitter. Do not stare at the light source.

Package Contents

1



2



3

Display

4

Note:

- Dust Mite Sensitivity refers to the degree of dirtiness of the mixture of dust mites, dandruff, and other dust pollutants in the mite-infested area.
- Dust Mite Vacuum Cleaner Status Indicator: Blue indicates normal operation, and flashing blue indicates the UV indicator is on. When the UV function is turned off, the indicator flashes blue.
- Dust Mite Vacuum Cleaner Mode Indicator: Blue indicates the low suction mode, and flashing blue indicates the high suction mode. When the UV function is turned off, the indicator flashes blue.
- Hot Air Dissipation Indicator: Blue indicates the hot air dissipation function is on. When the hot air dissipation function is turned off, the indicator flashes blue.
- During cleaning, a steady yellow or orange dust mite density indicator indicates a dust mite density of 10 or more. It is recommended to clean the area multiple times.

How to Use

Turning on/off

Turn on the dust mite vacuum cleaner to power, and press to power button to turn on.

The dust mite vacuum cleaner will enter the sleep mode after it is turned on.

Note: During use, hot air will come out from the heat dissipation vent. For first time use, it may produce a small amount of smoke from the cooling wire, and the odor will dissipate. Ventilate in time.



5

Switching modes

Turn on the dust mite vacuum cleaner, and press the mode button to switch from low suction, high suction, and UV mode.

Low suction mode: Suitable for daily cleaning of soft furniture and clothes.

Smart mode: Suitable for serious cleaning scenarios The dust mite vacuum cleaner automatically adjusts the suction power based on the dust mite density.

High suction mode: Suitable for deep cleaning hard-to-reach areas such as mattresses and pillows.

Installing the dust compartment assembly

Align the dust compartment groove with the protruding dust compartment switch, and push the dust compartment into a "click" indicating it is installed in place.



Care & Maintenance

WARNING: Before cleaning or maintaining the dust mite vacuum cleaner, turn it off and unplug it.

Do not use water to clean the dust mite vacuum cleaner and the dust mite brush cover. Wipe it with a dry cloth.

Do not use water to clean the dust compartment cover or hold it in the pressure jet, or it may cause damage to the dust mite vacuum cleaner in water for cleaning.

Daily cleaning of the dust compartment assembly

1. Press and hold the dust compartment release button, slightly disassemble and pull the dust compartment assembly.



2. Above the trash can, press and hold the "-" and of the dust cup cover removal button, open the dust cover, and pull the dust cup out. Remove the dust cover, open the dust cover, and pull the dust cover and the garbage in the dust cup, and shake the dust and filter on the surface of the dust cup cover.

3. After cleaning the garbage, install the dust compartment cover assembly. Align the dust compartment in the protruding groove on the bottom of the dust cup, and press the dust cup cover to the dust cup. Align the dust cup cover with the dust cup, and hold the dust cup and the dust compartment cover back until the dust cup cover is locked in place and "click" sound is heard, indicating the installation is successful.

4. Check that the buffer of the dust compartment assembly is intact, and install the dust cup and dust compartment assembly into the main body.

Washing the dust compartment assembly

Remove the dust compartment assembly promptly to regain the mite-removal performance and prevent drainage from the air duct that may cause the dust mite vacuum cleaner to malfunction.

1. Remove the dust compartment cover: Hold the stainless steel filter, and rotate it counterclockwise to the "unlocked" position, and remove it.

2. Remove the air inlet filter cotton from the air inlet of the dust cup.

4. Clean the cyclones of the dust compartment, dust compartment cover, cyclone separator, filter holder, filter, and filter cotton. Then install the dust compartment cover, filter, and air inlet filter.

(1) It is recommended to wash and clean the filter every 6 to 8 vacuuming, or when the suction power significantly decreases.

(2) It is recommended to replace the filter every 12 months.

(3) Do not disassemble the cyclone separator, or dry the components (away from direct sunlight) before re-installation.

5. When cleaning dust compartments, pull out the filter cover, the stainless steel filter, and the dust compartment cover, and rinse the dust compartment with water. Dry the components in the sunlight before installation to avoid mold.

6. Insert the air inlet cotton in the main unit air inlet parts, and install the dust compartment assembly into the main unit and lock it.

7. Lock the dust compartment and dust compartment cover assembly, and install the dust compartment assembly back to the main unit.

Cleaning the roller brush

1. Install the roller brush cleaner tool into the hole on the dust mite brush cover, and rotate the handle to open the dust mite brush cover.

2. Remove the roller brush from the dust mite vacuum cleaner, remove the hair and other sundries on the roller brush, and remove the hair and other sundries on the roller brush cleaner tool.

3. After cleaning, install the roller brush into the dust mite vacuum cleaner, and close the dust mite brush cover. Remove the roller brush cleaner tool, and lock the handle in the "open" position.

Clean the suction inlet and dust mite sensors

Remove the dust compartment assembly, and use a dry cloth to wipe the suction inlet and the sensor inlet. Clean them with a dry cloth or brush.

1. To ensure the dust and other particles to adhere to the suction inlet, Clean it regularly.

2. Do not use water to clean the dust mite vacuum cleaner, and do not use water to clean the dust mite sensor, or it may cause damage to the dust mite vacuum cleaner and affect the dust mite sensor.

3. Do not use other solvents to clean the dust mite sensor, or it may cause damage to the dust mite sensor. Do not use a hard object to scratch the dust mite sensor, or it may cause damage to the dust mite sensor.



8

Troubleshooting

Problem	Possible Causes	Solutions
The dust mite vacuum cleaner cannot be powered on.	The power cord is not connected properly.	Plug in the power cord properly.
	Insufficient power in the battery.	Charge the battery.
	The dust mite vacuum cleaner is in the sleep mode.	Press the power button to wake up.
The main motor of the dust mite vacuum cleaner does not rotate.	The dust compartment is not installed properly.	Install the dust compartment properly.
	The dust compartment is full.	Turn off and unplug the dust mite vacuum cleaner, and clean the dust compartment.
The suction decreases.	The filter is clogged.	Clean the filter and dust compartment.
	The filter is damaged.	Replace the filter.
The UV light is not on.	The dust compartment is not installed properly.	Install the dust compartment properly.
	The dust mite vacuum cleaner is in the sleep mode.	Press the power button to wake up.
	The UV function is turned off.	Turn on the UV function.
The dust mite brush does not rotate.	The dust mite brush is not installed properly.	Install the dust mite brush properly.
	The dust mite brush is jammed.	Remove the hair and other sundries on the dust mite brush.
The dust mite brush does not rotate.	The dust mite brush is not installed properly.	Install the dust mite brush properly.
	The dust mite brush is jammed.	Remove the hair and other sundries on the dust mite brush.
The dust mite brush does not rotate.	The dust mite brush is not installed properly.	Install the dust mite brush properly.
	The dust mite brush is jammed.	Remove the hair and other sundries on the dust mite brush.
The dust mite sensitivity indicator blinks orange.	The dust mite sensor is dirty.	Clean the dust mite sensor.

9

Specifications

Model: XIAOMI Mite Vacuum Cleaner
Rated Voltage: 220 V
Rated Power: 600 W
Size Dimensions: 257 × 298 × 225 mm

Model: A30C7B
Rated Voltage: 28 V
Rated Power: 180 W
Net Weight: 2.4 kg

10

For further information, please go to www.mi.com
Manufacturer: Xiaomi Communications Co., Ltd.
Manufacturer's Address: Xiaomi Technology Park, Qiaobei Road, Qiaobei, Qinghe, Haidian District, Beijing, China
Address: Rm 2, Longhua Road, Wisang Village Committee, Beiqiao Town, Yanqing District, Beijing, Beijing Yanqing Yongtai Zhong
User Manual Version: 1.0.0

11

12