


JUICE EXTRACTOR INSTRUCTION MANUAL



MJE-1845A

**PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY
BEFORE USING.**

IMPORTANT SAFETY INSTRUCTIONS

KEEP INSTRUCTION MANUAL SAFE FOR FUTURE USE

• **Be sure input voltage of the appliance before using: AC120V 60Hz**

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not use this appliance with a damaged cord or plug or when the appliance has malfunctions or has been damaged in any manner. To avoid a hazard, make sure that a damaged cord or plug will be replaced by a competent qualified repair service center. Do not repair this appliance yourself.
- To protect children against the dangers of electrical appliances, please make sure that you never leave the appliance unattended. Therefore, you have to storage the appliance where children are not able to grab it. Make sure that the cable is not hanging in a downward position.
- To protect yourself against an electric shock, do not immerse the cord, plug or appliance in the water or any other liquid.
- This appliance can be used by children aged from 12 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Always disconnect the device from the power supply if it is left unattended and before assembling, disassembling or cleaning.
- Never move the appliance by pulling the cord and make sure the cord cannot become entangled.
- The appliance must be placed on a stable, level surface.
- This appliance is only to be used for household purposes.


- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction
- Children being supervised not to play with the appliance
- The instructions shall include the operating times for accessories.
- Accessories, shall include instructions for their safe use.
- After use, unplug the power cord, open the transparent cover, blade disc, and juice spout, clean the residue thoroughly, then disassemble and rinse. Wipe dry with a cloth, reassemble, and store properly. The main body must never be rinsed under a faucet, nor cleaned in a dishwasher. Immersion in water is strictly prohibited.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the rotating sieve or the protecting cover is damaged or has visible cracks.
- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.

The appliance is for household use only.

PARTS DESCRIPTION

Product may vary slightly from illustrations.

1. Pusher
2. Feeding chute
3. Lid
4. Juicing filter
5. Filter holder
6. Adjustable Juice outlet
7. Locking arms
8. Motor coupler
9. Speed selector
10. Motor base
11. Pulp collector
12. Juice cup cover
13. Juice cup



BEFORE FIRST USE

- Remove the Power Juicer from the packing material.
- Before using your appliance for the first time, wipe off all removable parts with a damp cloth. Never use abrasive products.
- Place the device on a flat and stable surface and ensure a minimum of 10 cm. free space around the device. This device is not suitable for installation in a cabinet or for outside use.
- This product is equipped with dual security system and it will not start working before all the parts and component are installed correctly.

SPEED SETTING

The following settings can be selected:

P- Same as speed “2” to switched on and hold on the rotary knob at this position

0 - Switched off the appliance

1 - Low speed

2 - High speed

USING THE JUICE EXTRACTOR

Step 1. Make sure that the switch is in “0” position.

Step 2. Assemble the appliance according to “Parts Description”.

Step 3. Insert the plug into the wall so, according to the fruit or vegetable.

Step 4. Select the suitable speed level for the fruit or vegetable.

Step 5. Use the pusher to push the fruit or vegetable through the juicer opening.

Step 6. When the juice cup is full, stop the motor by switching it to “0” position.

TECHNICAL SPECIFICATION

Rated voltage AC120V

Frequency.....60Hz

Power.....400W

SELECTION OF FRUITS

- Containing much juice; suitable fruits conclude: pineapple, beetroot, celery, apple, cucumber, spinach, melon, tomato, mandarin orange and grape etc.
- Fruits and vegetables with thin skin are not required to peel but those with thick one such as mandarin orange, pineapple and raw beetroot are recommended to peel. Citrus fruits' seeds, which may cause bitter taste to juice, shall be removed.
- Fruits containing starch such as banana, papaya, avocado, figs and mango are not suitable to be put into juicer to make juice.

CLEANING AND MAINTENANCE

- Always remove the plug from the outlet before storage or cleaning the device then rinse the appliance with warm water.
- Unplug the appliance. Use a soft, slightly damp cloth to wipe appliance surfaces. Do not allow water or any other liquid to get into the unit.
- Components that come into contact with food can be cleaned in soapy water.
- The components are not suitable for cleaning in a dishwasher. If exposed to heat or caustic cleaners they might become misshapen or discolored.

CAUTION! The blades in the filter are very sharp, never try to replace them and be careful with the cleaning. Avoid to contact with the blades, they can seriously injure.