

WIRELESS MICROPHONE




Do not touch the sensor

PRODUCT INTRODUCTION

Dear user, thank you for choosing to use our wireless live broadcast system. This manual will provide you with a clear user guide to help you quickly get started and fully utilize the product's features.

This product consists of three parts: microphone, receiver, and charging compartment. We can provide professional-level recording and live streaming output, plug-and-play, without the need for an APP. It can be used for various live streaming, VLOG, video shooting, program interviews, interview recording, video teaching and other scenarios.



Charging compartment Microphone Receiver

OPERATING INSTRUCTIONS

1. Microphone

Function mode	Button operation	LED status
Power on	Long press the microphone button	Blue light
Stand-by	Long press the microphone button	Lighting off
Power off	-	Blue light lighting flash
Connect/disconnect	-	Blue light lighting flash
Use	Press 2 times	Blue light green light flash alternately. Blue light indicates video recording ON/OFF.
Microphone mute/unmute/adjust volume	Press 3 times	Blue light green light flash alternately. Blue light indicates video recording ON/OFF.
Microphone mute/unmute	Press 4 times	Green light lighting
Charging a complete	-	Blue green light flash on for 10 seconds
Light storage	-	Red light green light off
Low power alarm	-	Green light flash every 3 seconds
Low power shutdown	-	Green light flash every 3 seconds and 10s
Microphone	-	Lighting off (the microphone button is still lit)

In short words, switching to other modes is ineffective, and it will automatically shut down after 3 minutes of no connection.

OPERATING INSTRUCTIONS

2. Receiver

Function mode	Button operation	LED status
Power on	Plug in your phone	Connect to the light and turn on
Stand-by	Unplug the phone	Connect to the light and turn it off
Not connected	-	Connect to the light and turn on
Connected already	-	Connect to the light and turn on
Microphone mute/unmute	Press 3 times	Blue green light flash alternately
Microphone mute/unmute	Press 4 times	Green light flash alternately
Microphone mute/unmute	Press 5 times	Lighting off


3. Introduction to Receiver Charging



Using a Type-C charging cable on the side of the receiver can help charge and use the phone at the same time.

OPERATING INSTRUCTIONS

4. Introduction to charging compartment lights



Indicator light:
 1 light: 25%
 2 lights: 50%
 3 lights: 75%
 4 lights: 100%

Note: Use the Type-C charging port.

COMMON PROBLEM

Why can't I record normally after connecting my phone?

1. Please check if the connection indicator lights of the microphone and receiver are lit up.
2. Please check if the microphone battery is sufficient. If the battery is low, please charge it promptly.
3. Some Android and Huawei phones need to update their phone versions (Settings>My Device>Version>Check for updates). Some brands of mobile phones such as VIVO, OPPO, Honor/HiPhone, etc., require the "OTG" function to be turned on and an external recording device to be turned on (Settings>Other Settings>OTG>Open or search for "OTG" in the search bar in settings and open it). Step 2: Open External Device Process Settings>Sound and Vibration>More Sound Settings>Default Recording Device>External Device.

Can the microphone not record for the device's built-in camera app?

1. Some brands of mobile phones have strict system restrictions that prevent the microphone from obtaining video permissions, and due to the quality of the microphone. In this situation occurs, please contact the brand mobile phone manufacturer. This product is compatible with the vast majority of apps on the market. Please try using other apps instead.

Is there any noise in the recorded sound?

1. 1. Check if the microphone is turned on for noise reduction mode.

COMMON PROBLEM

Is the recorded sound unclear?

1. Please bring the microphone closer to the sound source to avoid sound distortion? Please click the microphone volume button on the receiver to increase the volume? Some brands of mobile phones, such as VIVO/OPPO, Honor, Xiaomi, OPPO, etc., require the "OTG" function to be turned on and external recording device to be turned on (please follow the first point of the FAQ).

What should I do if there is wind noise?

If you have purchased a model with a windproof cap, please install the windproof cap on the microphone.

What should I do if the phone cannot detect recording for low battery?

Please connect the charging cable to the charging port on the receiving end to charge the phone.

What if there is a response?

*Check if the microphone has enabled the video function (the third indicator light is on). Click the mute/unmute button to turn off the video. Enter the song request interface in the live broadcast room and set it to the original sound in the setting.

What should I do if there is an echo during the live broadcast?

Please turn off the sound of the mobile phone in the live streaming room otherwise there will be echoes (mobile phones in the same space cannot have sound when watching live streaming).

PRODUCT PARAMETERS

Minimum transmission	1000m
Sound delay	<20ms
Frequency response	20Hz-20kHz
Sensitivity	-38dB
Signal to Noise Ratio	>60dB
Transmission distance	10 meters (indoor) / 40 meters (outdoor)
Microphone	3rd degree full pickup
Battery life	Microphone: 40-100h (for use with charging case)
Battery capacity	Microphone: 200mAh
Input voltage	Charging compartment: 5V/1A
Adapter	5V/1A
Weight	Microphone: 3g, receiver: 4g, charging compartment: 45g
Size	Microphone: 45mm*15.5mm*17.5mm receiver: 45mm*17.5mm*17.5mm Charging compartment: 45mm*45mm*14.5mm

SAFETY PRECAUTIONS

1. The product contains strong magnetism. To avoid magnetization effects, please stay away from magnetic cards, C-card (magnetic), medical devices (such as pacemakers), hard drives, HDD chips, and other easily affected devices.
2. It is strictly prohibited to let the product come into contact with any liquid. Do not immerse the product in water or use it. Do not use the product in rainy or humid environments. Corrosion reactions may occur inside the product when it comes into contact with water, leading to spontaneous combustion or even explosion of the battery.
3. If the product catches fire, please immediately use water, water mist, sand, fire blankets, and carbon dioxide fire extinguishers to extinguish the fire. Please choose the fire extinguishing method according to the recommended order based on the actual situation.
4. Please use the product in an environment with a temperature between 0°C and 45°C. The charging environment temperature for the product is between 5°C and 45°C.
5. It is prohibited to disassemble the product in any way. If the battery is punctured during the disassembly process, it will cause leakage of electrolyte inside the battery, and even trigger a fire or explosion.
6. Mechanical impact, crushing, or throwing of products is prohibited. Do not place heavy objects on the product.
7. Do not place the product on the accessories or inside of heating equipment, cooking equipment, high-pressure containers, etc. (such as microwave ovens, battery ovens, electric ovens, electric heaters, pressure cookers, water heaters, gas stoves, etc.) to prevent battery overheating and explosion.

SAFETY PRECAUTIONS

8. It is prohibited to place the product near a heat source (stove or heater, etc.) or in a car on hot days. Do not store the product in an environment above 45°C.
9. Do not store the battery for a long time after completely discharging it in order to avoid the battery entering an overcharged state and causing damage to the battery cells, which will make it impossible to restore use.
10. The original matching model of charging case, data cable, and battery must be used.
11. Using unverified or non-matching charging case data cable batteries may cause electric shock, fire, explosion, or other hazardous situations unless to product version upgrades or other reasons, this manual may be updated periodically. Unless otherwise agreed, this document is only intended as a guide for use. All statements and suggestions in this document do not constitute any express or implied warranties.

