


Android AI Screen

User Manual

(English version)

한국어 설명서는 21 페이지로 이동하십시오.



Notes: The manual is applicable to the WIFI version of Android smart screen

User Manual	1
1. Product installation	3
2. Gesture operation	5
3. Function introduction	6
4. Mirror Link Description	7
5. The instruction of Carplay	10
6. The instruction of Android Auto	13
7. Audio out	14
8. Camera Function	15
9. Playback Function	16
10. Wallpaper Function	17
11. Music Features	17
12. More Applications	18
13. Menu language	18
14. System Update - OTA Remote Upgrade	19
15. Reminder & Fault resolution	20

1. Product installation

A. Power installation



You must use the power cord from the packaging box to connect the Type-C port to the machine and insert the other end into the car cigarette lighter port.



【Note: You cannot use data cables/mobile phone chargers/other chargers, non-standard voltage and current may cause the machine to fail to start or even be damaged】

B. GPS installation

The GPS must be facing upwards, installed above the windshield or at the front of the center console, and must be unobstructed except for the car glass

C. TF Card installation

Suggest using TF Card with 32G-128G, Class10/U3 or higher


Insert the chip into the smaller slot facing upwards



D. Rear camera installation


The red line of the rear camera needs to be connected to the positive pole of the reversing light. When reversing, the screen can automatically jump to the image behind it

Installation of the rear camera



【The appearance of the rear camera is not unique, please refer to the style in the package.】

2. Gesture operation



This function is similar to the full screen gesture operation of a mobile phone, and the specific operation is explained as follows



Swipe from the left to the right of the screen to return to the previous page



Swipe up from below the screen to return to the home page or recent taskbar interface



Swipe left from the right side of the screen to return to the previous page



Swipe down from above the screen to display the navigation bar/status bar

3. Function introduction

(1) Power button

① On/Off function

Long press for 3 seconds to turn on/off

② Screenshot Function

Long press the power button for 3 seconds to select the screenshot function

(2) Turn off monitor backlight

Short press to enter sleep or wake up to modify the sleep time in the settings


(3) Reset key

① The reset button is located at the R hole on the back and can be touched with a toothpick or sharp object to reset the machine


② Insert a toothpick into the rear camera hole and gently press the switch

inside to force a factory reset


(4). Main interface-【Different models may have different UI interfaces】



A、 Navigation: Click the navigation icon to enter the default map navigation.



Long press enter the navigation application interface, select the default navigation application.



B、 Mirror Link: Click can enter the wireless cast function
(please refer to attachment 1: Mirror Link Description)

4. Mirror Link Description

1, Turn on the wireless screen projection function of the device (as

shown in the figure)




- 1). Open the iPhone's screen cast interface
- 2). Open the mobile hotspot function, DVR connects the phone hotspot
- 3). The mobile phone control center selects "Screen Mirror"> "Screen Mirror" pop-up window Select the vehicle machine equipment. You can start screen mirror projection




- 4). Click the device model and connect successfully
- 5). When using the Apple AirPlay full -screen image, it needs to be operated on the mobile phone. It does not support anti -control, and the mobile phone cannot lock the screen.

2. Open the Android screen projection interface

- (1) Click on the icon  and follow the prompts to scan the device QR code



- (2) After scanning the QR code, it will prompt to download CarLetter Cast




- (3) Start the app and to connect to DVR Bluetooth
- (4) Open mobile hotspot, DVR needs to connect to mobile hotspot
- (5) Projection screen




(6) The Android Cast function needs to be transmitted with Bluetooth. Please ensure that the phone connects with the DVR Bluetooth before using this function.

(7) Use the Android Cast full -screen image to operate on the mobile phone, do not support anti -control, and mobile phones cannot lock the screen


C、**Carplay**: Click  can enter CarPlay -related functions

5. The instruction of Carplay

1. Open the device CARPLAY function (as shown in the figure)




2. Open the Bluetooth of the Bluetooth search device in the upper right corner of the mobile phone (as shown in the figure)




Note: 【 Bluetooth password: 0000 Or automatically pair with a random password 】 The name of each device Bluetooth is different



1. After the mobile phone Bluetooth connection, there will be a prompt box to use CarPlay car, click to use CarPlay car





2. Device CarPlay connection




3. After the Carplay connection is completed, functions on mobile phones such as maps, music, call, and SMS are synchronized to DVR.



4. Click  to return to the recorder interface




D、**Android Auto**： Click  can enter Android Auto - related


functions

6. The instruction of Android Auto

1. Open the device Android Auto function (as shown in the figure)





2. Open the Bluetooth of the Bluetooth search device in the upper right corner of the equipment Bluetooth name (as shown in the figure)




Note: The name of each device Bluetooth is different


1. When the mobile phone is connected, it is prompted to enter the PIN code. Usually 0000 or 1234
2. After the Carplay connection is completed, functions on mobile phones such as maps, music, call, and SMS are synchronized to DVR.




3. Click  to return to the recorder interface

7.Audio out



click  Enter audio output function



1、 **Native audio:** Select this option, the device will play the sound.


2、 **AUX audio:** Select this option, please ensure that the AUX cable is properly connected and the car audio system is set up correctly, and the sound is played through

the car audio system.


3、 BT audio:


①**Carplay/Android Auto mode:** When selecting the Bluetooth audio option in this mode, the device will not produce sound. Please use a phone connected to the device and reconnect to the car Bluetooth speaker. The sound will be played through the car speaker

②Android OS Mode:

Click  [More settings] connecting the vehicle Bluetooth

8.Camera Function




Click  Enter the camera interface, default front camera screen



1. Click on the screen to switch between front/rear cameras
2. Double click the screen to enter full screen mode. In full screen mode, swipe the

screen up and down to adjust the camera's field of view



3. Click  Enter camera settings



Click confirm to format TF Card, which can solve the common problem of TF Card not being able to record




Turn on the streaming switch and default to the rear camera screen when turning on (the rear camera must already be installed)




4. Camera can flip the image

9. Playback Function





Click Enter the dash cam recording video playback function



You can view your recorded videos/photos here


10. Wallpaper Function




Click  Enter the Wallpaper management function

This feature currently only supports changing the wallpaper of the secondary menu, and the wallpaper of the main interface cannot be changed

11. Music Features



① Click  can enter the TF Card interface, which can play videos, music, pictures

(1) Video: support MP4、MOV、3GP、MKV、FLV、WMV, NOT support 2K and 4K resolution video、VOB、RMVB、MPG

(2) Music: support MP3、ogg、aac、flac、wav, NOT support WMA、ape


(3)Picture: support JPG、BMP

②You can enter to download and install more music apps for use

12.More Applications




When scrolling from right to left on the main interface, you will see the secondary menu of the device, which contains all the applications of the device



13.Menu language

Click sequentially






Press and hold  The language you want is given first priority


Click  Add a language Add more languages

14. System Update - OTA Remote Upgrade

1. Firstly, send us the device version number and IEMI number through a buyer's conversation



2. Connect to the WIFI network and click on Settings
3. Click on 'About Devices'
4. Click on the upgrade button
5. Check for updates and then download the upgrade



5. After the update is completed, the factory settings must be restored once

【 If the device can be used normally without any malfunctions, it is not recommended to upgrade the system as it may cause system instability. 】

15. Reminder & Fault resolution

1. Do not arbitrarily squeeze the dash cam
2. Please use the original charger
3. Most software failures can be resolved by restoring the factory settings
4. The base can be removed from the bottom three screws and installed in the opposite direction to obtain different angles
5. If you need to install the suction cup bracket, please remove the sticker on the back of the machine
6. For more questions, please contact the seller's customer service

Sincere wishes for your convenience and assistance in using our product. If you have any questions, please contact the merchant's customer service and we will solve them for you.

Android AI Screen

사용자 안내서

(한국어 버전)



참고: 이 설명서는 WiFi 버전의 안드로이드 스마트 스크린
에 적용됩니다.

1. 제품 설치	23
2. 제스처 조작	25
3. 기능 소개	26
4. 핸드폰 화면 투영	27
5. Carplay 지침	30
6. Android Auto 의사용법	33
7. 오디오아웃	34
8. 카메라 설정	35
9. 녹화된 비디오 재생	36
10. 벽지 기능	37
11. 음악 기능	37
12. 추가 애플리케이션	38
13. 메뉴 언어	38
14. 시스템업데이트-OTA 원격업그레이드	39
15. 리마인더&고장해결	40

1. 제품 설치

A. 전원 설치



원래 전원 코드를 사용하여 C 포트를 기계에 연결하고 다른 쪽 끝을 자동차 점화기 포트에 꽂아야 합니다.



【참고: 데이터 케이블/휴대폰 충전기/기타 충전기를 사용할 수 없습니다. 표준화되지 않은 전압과 전류는 기계가 작동하지 않거나 심지어 손상될 수 있습니다.】

B.GPS 설치

GPS 는 반드시 위로 향하고, 바람막이 유리 위나 중앙제어대 앞부분에 설치해야 하며, 자동차 유리를 제외하고는 반드시 막힘이 없어야 한다

C.TF 카드 설치


32G-128G, Class10/U3 이상의 TF 카드 권장
작은 슬롯에 칩 평면 위쪽 삽입



D. 후면 카메라 설치


후면 카메라의 빨간색 선은 후진등의 양극에 연결되어야 한다.후진 시 화면 은 자동으로 뒤쪽 이미지 로 이동할 수 있다

Installation of the rear camera



【후면 카메라의 외관은 독특하지 않으니 포장 중의 스타일을 참고하세요.】

2. 제스처 조작



이 기능은 휴대폰의 전체 화면 제스처와 유사합니다.

 화면 왼쪽에서 오른쪽으로 이동하여 이전 페이지로 돌아갑니다.



화면 아래에서 위로 이동하여 홈 페이지 또는 최근 작업 표시줄 인터페이스로 돌아가기



화면 오른쪽에서 왼쪽으로 이동하여 이전 페이지로 돌아갑니다.



화면의 위쪽에서 아래로 이동하여 탐색 모음 / 상태 표시줄을 표시합니다.

3. 기능 소개

(1) 전원 버튼

① 켜기 / 끄기 기능

3 초 동안 길게 눌러 켜기 / 끄기

②캡처 기능

전원 버튼을 3 초 동안 길게 누르고 캡처 기능 선택

(2) 모니터 백라이트 끄기

짧게 누르면 수면 상태에 들어갈 수 있고, 짧게 누르면 설정에서 수면 시간을 수정할 수 있다


(3) 재설정 키

①리셋 버튼은 뒷면의 R 구멍에 위치하며 이쑤시개나 뾰족한 물체로 터치하여 기계를 리셋할 수 있다


②이쑤시개를 후면 카메라 구멍에 삽입하고 안쪽의 스위치를 살

딱 눌러 출하 시 설정을 강제로 복원합니다.

(4) 메인 인터페이스-모델에 따라 UI 인터페이스가 다를 수 있음




A、탐색: 기본지도탐색을입력하려면탐색아이콘을클릭합니다



내비게이션을길게누르시면자신이원하는내비를선택할수있습니다

B、Mirror Link: Click



미러링크에들어가시면스마트폰을미

러링할수있게할수있습니다。


아이폰은카플레이모양갤럭시는안드로이드오토모양을선택해주세요!

4. 핸드폰 화면 투영

1, 장 치 의 무 선 화 면 투 사 기 능 을 컵 니 다 (그 림 과 같 이)



- 1).아이폰의스크린캐스트인터페이스를업니다
- 2).모바일핫스팟기능을열면 DVR 이전화핫스팟을연결합니다
- 3).휴대폰제어센터에서"스크린미러">"스크린미러"팝업창선택차량기계장비를선택합니다。



스크린미러투사를시작할수있습니다

- 4).장치모델을클릭하고성공적으로연결합니다
- 5).Apple AirPlay 풀스크린이미지를사용하는경우휴대폰으로조작해야 합니다. 안티컨트들을지원하지


2.Android 화면프로젝션인터페이스열기

- (7)  이아이콘을클릭하시면안드로이드의경우 QR 코드가나오며 프로그램을

설치해주시면됩니다。



(2)QR 코드를스캔하면 CarLetter Cast 를다운로드하라는메시지가표시됩니다



3)앱을시작하고 DVR Bluetooth 에연결하기

(4)모바일핫스팟을열고 DVR 을모바일핫스팟에연결해야함

(5)프로젝션화면




(6)안드로이드캐스트기능은블루투스로전송해야합니다.

이기능을사용하기전에전화기가 DVR 블루투스와연결되어있는지확인 하십시오.

(7)Android Cast 전체화면이미지를사용하여휴대전화에서작동하고, 안 티컨트롤을지원하지

않으며, 휴대전화는화면을잠글수없습니다


Carplay:



CarPlay 관련 기능에 접속할 수 있습니다.

5. Carplay 지침

2. 장치 CARPLAY 기능을 엽니다 (그림에서와같이)



2.휴대폰우측상단에있는블루투스검색기의블루투스를염니다(그림참조)




3.참고: 【Bluetooth 암호: 0000 또는 임의 암호와 자동으로 페어링】각장치
의이름블루투스가다릅니다

4.휴대폰블루투스연결후 CarPlay 자동차사용안내창이뜨며클릭하면 CarPlay 자동





차를사용할수있습니다

5.장치카플레이연결



6.카플레이연결이완료되면지도, 음악, 통화, SMS 등휴대폰의기능이 DVR 에 동기화됩니다.




클릭  녹음기인터페이스로되돌아가다


Android Auto: 클릭  Android Auto 관련기능입력가능

6. Android Auto 의사용법

1.장치 Android Auto(안드로이드자동)기능을업니다 (그림참조)




2.장비의우측상단모서리에있는블루투스검색장치의블루투스를업니다. 블루투스이름은 그림과같습니다




를연결하여 Android 전화연결을활성화하십시오

- 1.휴대전화가연결되면 PIN 코드를입력하라는메시지가나타납니다. 보통 0000 또는 1234
- 2.카플레이연결이완료되면지도, 음악, 통화, SMS 등휴대폰의기능이 DVR 에 동기화됩니다.




클릭 **Exit** 녹음기인터페이스로되돌아가다

7. 오디오아웃



클릭 **Audio Out** 오디오 출력 들어가기



- 1、로컬오디오: 이 옵션을 선택하면 장치에서 사운드를 재생합니다.
- 2、AUX 오디오: 이 옵션을 선택하면 AUX 케이블이 올바르게 연결되어 있고 자동차 오디오 시스템이 올바르게 설정되어 있으며 소리가 자동차 오디오 시스템을 통해 재생되는지 확인하십시오.


3、Bluetooth 오디오

①**Carplay/Android Auto mode:** 이 모드에서 Bluetooth 오디오 옵션을 선택하면 장치에서 소리가 나지 않습니다. 기기에 연결된 휴대폰을 사용하고 자동차 블루투스 스피커에 다시 연결하십시오. 소리가 자동차 스피커를 통해 재생될 것입니다

②**Android os Mode:**

클릭  [추가 설정] 차량 블루투스 연결

8. 카메라 설정

클릭  카메라 인터페이스로 이동, 기본 전면 카메라 화면



1. 화면을 클릭하여 앞뒤 카메라 사이를 전환

2. 화면을 두 번 클릭하여 전체 화면 모드로 이동합니다.전체 화면 모드에서 화면을 위아래로 슬라이드하여 카메라 시야를 조정합니다.

3.클릭  카메라 설정 입력

TF카드 포맷

확인

TF 카드 포맷 확인을 클릭하면 TF 카드가 기록할 수 없는 일반적인 문제를 해결할 수 있습니다.

전후 카메라 전환



스트리밍 스위치를 켜면 기본적으로 후면 카메라 화면이 켜집니다 (후면 카메라는 이미 설치되어 있어야 함).

설정		← 나가기	
V1.0.0_2024120515			
TF카드 포맷	확인	전후 카메라 전환	☐
녹화 시간	☒ 1min ☐ 2min ☐ 3min ☐ 4min ☐ 5min		
충돌 잠금 민감도	☐ 높음 ☒ 중간 ☐ 낮음 ☐ 끄기		
속도 단위	☒ km/h ☐ mph		
렌즈 높이 조절	☒ 백미러 ☐ 중앙 제어대 ☐ 차 머리 없음	현재 교정 모드로 들어가기	

카메라 수평 회전 : 앞쪽




뒤쪽




카메라는 이미지를 뒤집을 수 있다

9. 녹화된 비디오 재생




클릭

주행기록기 녹화 재생 기능에 들어간다




10. 벽지 기능



클릭 배경 화면 관리 기능 사용

이 기능은 현재 보조 메뉴의 배경 화면만 지원하며 기본 인터페이스의 배경 화면은 변경할 수 없습니다.

11. 음악 기능



①클릭 하여 TF 카드에 들어가면 동영상, 음악, 사진을 재생할 수 있다

(1) 비디오: MP4, MOV, 3GP, MKV, FLV, WMV 지원, 2K 및 4K 해상도 비디오, VOB, RMVB, MPG 지원 안 함


(2) 음악: MP3, ogg, aac, flac, wav 지원, WMA, ape 지원 안 함

(3) 사진: JPG, BMP 지원

② 다운로드하여 더 많은 음악 응용 프로그램을 설치할 수 있습니다.

12. 추가 애플리케이션


 주 인터페이스에서 오른쪽에서 왼쪽으로 스크롤하면 디바이스의 모든 응용 프로그램이 포함된 디바이스의 2 단계 메뉴가 표시됩니다.



13. 메뉴 언어

순차적 클릭





누르다 = 원하는 언어에 우선 순위 지정

클릭 + Add a language 언어 추가

14. 시스템업데이트-OTA 원격업그레이드

2. 우선바이어와의대화를통해디바이스버전번호와 IEMI 번호를 보내주세요




2. WIFI 네트워크에 연결하고 Settings(설정)을 클릭합니다

3. 'About Devices(장치정보)' 클릭

4. 업그레이드 버튼 클릭

5. 업데이트 확인 후 업그레이드 다운로드 (아래 그림과 같이)

6. 업데이트가 완료되면 공장 설정을 한 번 복원해야 합니다.



【장애 없이 디바이스를 정상적으로 사용할 수 있는 경우에는 시스템 불안정이 발생할 수 있으므로 시스템 업그레이드를 권장하지 않습니다.】

15. 리마인더&고장해결

1. 운행기록기를 함부로 누르지 마라
2. 기본 충전기를 사용하십시오.
3. 대부분의 소프트웨어 장애는 출하 시 복구를 통해 해결 가능
4. 받침대는 아래쪽에서 세 개의 나사를 분리하여 반대 방향으로 설치하여 다른 각도를 얻을 수 있다
5. 흡판 브래킷을 설치해야 한다면 기계 뒷면의 라벨을 떼어내십시오
6. 더 많은 문제가 있으면 판매자 고객센터에 연락하십시오.

귀하가 저희 제품을 사용할 때 편리하고 도움이 되기를 진심으로 축원합니다.궁금한 점이 있으시면 고객센터에 문의하시면 저희가 해결해 드리겠습니다.