

# USER MANUAL

## Wireless Vacuum Cleaner

PCMOS

Dual Use for Home and Car • High Power • Black

---

### PRODUCT DESCRIPTION

This wireless vacuum cleaner is designed for dual use in home and car. It features high power, strong suction, cordless operation, and lightweight design for easy cleaning of dust, debris, pet hair, and small particles.

**Model:** PCMOS Wireless Vacuum Cleaner **Color:** Black **Usage:** Home & Car Dual Use **Type:** Cordless, rechargeable, high power **Package includes:** 1 × Wireless Vacuum Cleaner 1 × Charging cable 1 × Nozzle accessories

---

### OPERATION INSTRUCTIONS

1. Fully charge the vacuum cleaner before first use.
  2. Press the power button to turn on/off the device.
  3. Select suitable nozzle for different cleaning scenarios.
  4. Use on dry surfaces only; do not use on wet or liquid areas.
  5. After use, turn off the vacuum and clean the filter and dust cup.
- 

### CHARGING INSTRUCTIONS

- Connect the charging cable to the vacuum and a USB power source.
  - Charge until the indicator shows full.
  - Do not charge for an excessively long time.
  - Use only the provided charging accessories.
-

## SAFETY INSTRUCTIONS

- For dry use only; do not absorb water or liquids.
  - Do not use when damaged, overheating, or abnormal.
  - Keep away from fire, high temperature, and water.
  - Do not disassemble, modify, or short-circuit the battery.
  - Keep out of reach of children and infants.
  - Do not block the air inlet or outlet during operation.
- 

## MAINTENANCE & CARE

- Regularly clean the dust cup and filter to maintain suction.
  - Do not wash the motor part; only clean the dust container.
  - Store in a cool, dry place away from moisture and direct sunlight.
  - Remove the battery (if removable) during long-term storage.
- 

## CE COMPLIANCE

This product complies with the following EU directives:

- 2014/35/EU (LVD)
  - 2014/30/EU (EMC)
  - 2011/65/EU (RoHS)
- 

© 2026 PCMOS. All Rights Reserved. </center>

---