

I. Instructions for Use

1. Unpacking Inspection: After opening the package, verify that the product is complete and undamaged.
2. Installation and Setup: Correctly install product components following the steps outlined in this manual.
3. Normal Operation: Power on the device and operate it according to the instructions provided.
4. Cleaning and Maintenance: Wipe off surface dust or stains promptly after use.
5. Storage Method: When not in use, store the product in a dry, well-ventilated location.

II. Precautions

1. Avoid Moisture: Do not use the product outdoors during rain or in high-humidity environments.
2. Do Not Disassemble: Unauthorized disassembly or repair by non-professionals is strictly prohibited.
3. Power Safety: Before use, ensure the power outlet is intact and undamaged.
4. Prevent Dropping: Avoid dropping the product from elevated positions to prevent damage.
5. Keep Children Away: Ensure children remain clear of the operational area during use.

III. Feature Overview

1. Multi-functional Design: Suitable for various scenarios and capable of meeting diverse user needs.
2. User-Friendly Operation: Intuitive interface design, suitable for users of all experience levels.
3. Energy-Efficient Performance: Low-power operation helps conserve electrical energy.

IV. Safety Warnings and Precautions

⚠ WARNING: Read all instructions carefully before using this product. Keep this manual for future reference.

⚠ WARNING: Do not use the product for any purpose other than its intended use. Misuse may cause injury, damage to the product, or other hazards.

⚠ WARNING: Keep this product out of the reach of children under 3 years, unless under direct adult supervision. Small parts may cause choking hazard.

⚠ WARNING: Do not disassemble, modify, or repair the product by yourself. Improper operation may cause electric shock, fire, or product failure. Contact professional maintenance personnel if needed.

⚠ WARNING: Dispose of the product and its packaging in accordance with EU WEEE (Waste Electrical and Electronic Equipment) Directive 2012/19/EU and RoHS Directive 2011/65/EU. Do not discard as household waste.

⚠ ATTENTION: Not suitable for children under 36 months. Contains small parts that may cause choking hazard. Use under adult supervision.

⚠ WARNING: Do not use the product near water or in humid environments. Avoid contact with liquids to prevent electric shock. Unplug the power supply when not in use or during cleaning

⚠ ATTENTION: Protective equipment should be worn. Not to be used in traffic. This product requires high skills to avoid falls or collisions.

⚠ ATTENTION: Only to be used in water in which the child is within its depth and under adult supervision.

⚠ ATTENTION: Not suitable for children under 3 years. For use under adult supervision. Contains substances that may cause irritation if misused. Follow the instructions strictly.