



Smart XE

Product List

Before use, please check carefully if the package contains all the following items. If missing, please contact our customer service or your dealer.

- **Phone Stabilizer**
- **Tripod**
- **Type-C Cable**
- **User Manual**



APP and Tutorials

1. Download APP

Please scan below QR code
or search **"AOCHUAN"** in
your APP store to download
our official APP.



Support IOS / Android



Download on the
App Store



Download for
Android



2. Watch video tutorials



YouTube

For more tutorial videos, please
scan YouTube QR code



Instagram

For more exciting events and
help, please follow us at
Instagram

Unfolding and Folding Gimbal

■ Unfolding Gimbal

Grip the arm of SMART XE gimbal and unfold it without unlocking. Mount your cellphone to the clip then level it up to start using.



■ Folding Gimbal

Rotate the gimbal arm until its folding position aligns with the operation panel; Fasten the tilt axis buckle; Make the mobile clip buckle inside, then fold the gimbal arm as per the direction of yellow arrow.

Product Information



Product Information




Operation Panel Information

1 Indication of gimbal mode

-  Normal mode
-  Cool mode
-  Rotation mode
-  Go mode
-  Bluetooth connected (indicator on)
Bluetooth disconnected (indicator off)



Battery life indication



F indicator double flashes when battery life is less than 15%.

2



Joystick: move up / down / left / right

Single click: switch F / POV

Double click: reposition

Triple click: DM / Automatic rotation

Hold down: Go mode

Operation Panel Information

3



Focus roller(need connect APP):

Adjust focus point / virtual and real

4



Zoom toggle(need connect APP):

Adjust focal length / distance

5



Single click: Photo / Video

Double click: switch landscape / portrait

6



Long press: power on / off

Double click: check battery life



Charging the Gimbal

■ Charging the Gimbal

Use the equipped Type-C cable to connect power adapter and the charging port in gimbal's handle. The gimbal is in charging state when indicator is on; When [••••] full bars show, the gimbal battery is fully charged.



The battery of SMART XE was already mounted in battery tank ahead of shipment. Before first use, please fully charge SMART XE to activate it for normal use.

Product Parameters

Product size	273*125*65mm (Unfolded size)
	163*108*55mm (Folded size)
Product weight	350g±5g
Payload	≤250g
Battery life	About 10 hours
Charging time	About 3.5 hours
Working voltage	3.7V
Power Input	5V/1A
Working temperature	0°C-55°C
Li-ion battery	3.7V/2600mAh
Fit for cellphone width	55-90mm
Angle accuracy	0.01°
Mechanical pan angles	310°
Mechanical roll angles	337°
Mechanical tilt angles	345°
Controllable pan angles	275°
Controllable roll angles	318°
Controllable tilt angles	83°

Above data stems from the testing data in the laboratory. The actual data is subject to vary to some extent under different testing conditions. Please refer to the real using experience.

Warranty Terms

1. Within 15 days from the date of purchase, the product with any functional malfunction or quality problems will be replaced for free, under the premise that the product and packaging are not damaged. We will offer a brand new one after confirming the product problem.

2. The product will enjoy 1-year free warranty for use under normal conditions (all accidental or artificial damages, and damages caused by improper disassembly or misuse are NOT covered by the warranty).

3. Please keep and offer the warranty card for claiming the warranty service.



connect us on facebook

E-mail: aochuan_gimbal@outlook.com

WEB: WWW.YG-FREE.COM

ADDR: 4th Floor and Half of the 3rd Floor, No.9 Huayuan Road, Xiaolan Town, Zhongshan City, Guangdong Province, China

Warranty Card

Customer Information

Customer Name:

Phone Number:

Address:

Sales Information

Sales date:

Product Serial Number:

Distributor Name:

Distributor's Contact Number:

First Maintenance Record

Service Date:

Repairman Signature:

Cause of Problem:

Service Result: ☐ Solved ☐ Unsolved ☐ Refunded/Replaced