




PENDANT LIGHT INSTALLATION INSTRUCTION



1



2



3

WE SUGGEST THE LAMP TO BE INSTALLED BY A LICENSED ELECTRICIAN.

Voltage:


110V-240V, Bulb Base Type: E26/E27.?

2. All wires are connected. When unpacking, be careful not to pull with wires as a bad connection may result.?

3. Do not connect electricity until your fixture is fully assembled.?

4. To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug fixture ?and allow it to cool prior to replacing light bulb.?

5. Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable ?materials away from lit bulb.



4