

English

Instruction Manual

1 Product Name: Home Furnishings

2 Usage method

1. Take out the product, check if the appearance is intact, and confirm that there is no damage, deformation, or missing accessories before use.
2. Place the product in a stable and dry place according to its intended use, avoiding high temperatures, humid environments, and sharp objects.
3. If assembly is required, check the parts according to the accessory list, follow the simple assembly instructions for splicing, and ensure that the connection is firm.
4. Handle with care during daily use to avoid excessive squeezing and impact, and prevent product damage.

3 Precautions

1. Overloading is prohibited to avoid exceeding the product's load-bearing capacity or applicable range, in order to prevent breakage and damage.
2. Minors must be supervised by adults when using it, and small accessories must be properly stored to prevent accidental ingestion or loss.
3. Avoid contact with corrosive liquids (such as disinfectant, vinegar, laundry detergent, etc.) to prevent damage to the surface of the product.
4. Stop using the product immediately if it is damaged or loose, and do not force it to cause safety hazards.

4 Cleaning and maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth to remove dust, and avoid washing with water (except for waterproof models).
2. After cleaning, place it in a ventilated place to dry. Do not expose it to direct sunlight or dry it to prevent material deformation and fading.
3. When not in use for a long time, clean it and store it in a dry and ventilated place to avoid squeezing and stacking.

한국어

사용 설명서

1

2

1. 제품을 꺼내 외관이完好한지 확인하고, 사용 전 손상, 변형, 부품 누락이 없는지 확인하십시오.
2. 제품의 용도에 따라 안정적이고 건조한 곳에 보관하십시오. 고온, 다습한 환경
person
3. 조립이 필요한 경우, 부품 목록에 따라 부품을 확인하고 간단한 조립 지침에 따라
접합하며 연결이 견고한지 확인하십시오.
4. 일상 사용 시 부드럽게 취급하여 과도한 압착 및 충격을 피하고 제품 손상을 방지
Person

3

1. .
하여 파손 및 손상을 방지하십시오.
2. 미성년자는 성인의 지도 하에 사용해야 하며, 작은 부품은 적절히 보관하여 실수로 삼키거나 분실하는 것을 방지하십시오.
3. 부식성 액체(소독제, 식초, 세탁세제 등)와의 접촉을 피하여 제품 표면 손상을 방지하십시오.
4. 제품에 손상이나 느슨해짐이 발생하면 즉시 사용을 중단하고, 강제로 사용하여 안전 위험을 유발하지 마십시오.

4

1. 일상 청소는 마른 천 또는 약간 젖은 부드러운 천으로 표면을 닦아 먼지를 제거하
..
2. .
.
3. 장기간 사용하지 않을 때는 청소한 후 건조하고 통풍이 양호한 곳에 보관하십시오
..

Polish

User Manual

1. Product Name: Household Goods

2 How to use

- 1.Remove the product, check if the appearance is intact, and make sure there are no defects.
damage, deformation, or missing parts before use.
- 2.Place the product in a stable and dry place according to its intended use.
Avoid high temperatures, damp environments, and sharp objects.

3.If assembly is required, check the parts according to the accessory list, proceed accordingly.
Follow the simple assembly instructions during connection and make sure that the connection is solid.

4.Handle gently during daily use, avoid excessive pressure.
and impacts to prevent damage to the product.

3. Safety Notes

1.Do not cut it to avoid exceeding the product's load capacity or range of application, in order to prevent cracking and damage.

2.Children should only use them under adult supervision, and small accessories should be stored properly to prevent accidental ingestion or spent.

3.Avoid contact with corrosive liquids (e.g.Disinfectants, vinegar, powder for washing, etc.) to prevent damage to the product's surface.

4.Immediately stop using the product if it is damaged or loose, and do not Use it forcefully, but do not cause any safety risks.

4. Cleaning and maintenance

1.For daily cleaning, wipe the surface with a dry cloth or lightly
Use a damp soft cloth to remove dust, avoid washing with water (except for waterproof models.

2.After cleaning, place in a ventilated area to dry.Do not display
Avoid direct sunlight or drying to prevent deformation and color damage.
material.

3.When not in use for a long time, clean it and store it in a dry and
in a ventilated place, avoid overlapping.

Ελλiηiκά

Example Χρoης

1¶'Ονομα Προϊόντος: Είδη για το σπιτι

2¶Τρόπο Χρoης

1. I will try to do it better.

ι δε εε ο η εεωε εεαε ρ τ
χρηον.

2. πθετησε ρι ε σταθε αι εη μερ σύμωνα με
First, let's start from the beginning, and let's see.
αξιόλογος αβίκειμεβα.

3.Home, you can control it with your smartphone.
ν εξαεων, αλθεελ πλε δγε σλογσ ι τ δε
α βεβαυθεε ι νδε ε αθεη.

4.Start with a small step and gradually move forward.
merbl tre i ai oeoeε ρι ε.

3||00

1.The price is for a certain capacity.

φοιη ε ε πιρέ, ρεμέ α αεύ
damage to the body.

2.Oh, I've seen it before and I remember it.

Sorry, I'm afraid I have to help you a little bit.

αττοφευχον χαα αατο η απλεια.

3. εε εαη με βη (τω ταα εδι, σαύν

for pltp.lt) oh

4.Oh, oh,

χρσίμτισσε με βα γία να μην τρληθ νδνοί ασφαλεα.

4||Καθαρισμό και Συνηηση

1. ια θε θ, ε εε ε εη εα η

el γ μα εα ια α ααεοεε σ, α τεε ο

plus e o eodβ εα.

2.Με αδσ, εηε ε εε εε μα α α

εει m εθεε ε ε λ η εε γ εχ η

I'm sorry, the translation of "μου χαα μου υλιού" is "I'm sorry, the translation of 'μου χαα μου υλιού' is..."

3.'Οταν δεν χστοεαί γία μεγαλ χρν διάστα, αθαρίεε ο αι

Please forgive me, or else I'll be in trouble.

Рысскñŭ

РыкоВосТВО nO KCñnyaaN

1||Ha3BaHne npoykta: ToBapbi Ag oma

2||Cnoco ncnonb3obaHn

1.Bbinakyŭe npoykt, npoBepbte Bhewh B ha enocthoctb, yenecb B

otcytctBn noee, eopan oycTByio,nx komnnektyionx nepen

NCNONb3OBaHHeM.

2.Pa3mectnte npoaykT B ctannbhom n cyxom mecte b cootbetctbnn c ero

ha3hayehnem, n3era Bbicokx temnepatyp, bnakhbix cpe octpbix npemetoB.

3. pn heoxommoctn copkn npobepbte etann no cñcky komnnektylounx,

conpauŭte npocbie nhctpykunn no copke npn coenheln n yentecb B

npoyHOCTn COenHeHna.

4. Pn nobceheBhom ncnonb3oBaHnn opawatecb c npoykтом octopoho,

n3eraŭte upe3mephoro cxaтn μ yapob, npeotbpawag nobpeehe npoykta.

3. Препоречуваме

1. Запаметете го, ако имате проблем со производот, тогаш не се плашајте да го вратите.

Ana3oh nmeheh npoykta, npeotBpawa pa3pbiB nobpekehne.

2. HecobepweHhonethne onHbl nonb3oBatbC npoykTom no npncmotpom

B3pocnbix, the connection is not working, I can't use the product at all.

ytobi npeotbpatntb cnyayãhoe npornatbibahne nnin notepro.

3. N3erate kohtata koppo3hbimn koctamn (takmn kak

e3hnpyow, ne cpectBa, ycyc, ctpanbHbl nopowok t..), uobi

npeoTbpaTnTb noBpekehne noBepxHocTn nroykta.

4. Meanehho npekpatnte ncnonb3obahne nponykta npn ohaupyehnn

nobpexehnã nnn ocanehn, he ncnonb3yãte ero hacnnibctbehho, utobi he

Bbl3BaTb onachocTb Oñg e3onachocTn.

4. Означения

1. No problem, I have no problem with the product, it is very good and I am satisfied.

Bnao r n n ya bin, eae mbi (om

BoohenpoHnaembix moene.

2. You will find a better game in the next game. He

Bbictabnaãte ha npambie conheyhbie nyun nnin cywnte, utobi npeotbpatntb

necopmanlo matepnana n Bbiy, betahne.

3. The phone is currently not working properly.

npobetpehhom mecte, n3eraãte cxatn n ctonkn.

Hrvatski

Instructions for use

1. Product name: Household items

2. Način uporabe

1. Take out the product, check whether the appearance is intact, confirm that there is no damage damage, deformation, or lack of accessories before use.

2. Place the product in a stable, dry place according to its intended use.

Avoid high temperatures, humid environments, and sharp objects.

3. If assembly is required, please check the parts according to the accessories list, follow simple assembly instructions when connecting, ensure that the connection is firm.

4. During daily use, handle it gently, avoid excessive pressure and

Air will prevent the product from being damaged.

3. Notes

1. Overloading is prohibited to avoid exceeding the load capacity

of the product or the area of use, in order to prevent breakage or damage.

2.Minors can only use the product under adult supervision, and small Accessories should be properly stored to prevent accidental ingestion or loss.

3.Avoid contact with corrosive liquids (e.g.dezinfekti, oct, prašak za washing, etc.)in order to prevent damage to the product's surface.

4.Immediately stop using the product if it is damaged or loose, and do not use it. use it forcefully to prevent any safety hazards.

4. Cleaning and maintenance

1.For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth. As for removing dust, avoid washing with water (except for waterproof models).

2.After cleaning, place it in a ventilated place to dry.Please don't do it Expose to direct sunlight or dry to prevent deformation and color fading. materijala.

3.When not in use for a long time, clean the air vents with a dry cloth. place, avoid pressure and rubbing.

German

Instruction Manual

1. Product Name: Household Items

2. Verwendungsweise

1.Take out the product and check whether its appearance is intact. and ensure that there are no damages, deformations, or Missing accessories are present.

2.Place the product on a stable surface according to its intended use. and store in a dry place, avoiding high temperatures, damp environments and sharp objects.

3.If assembly is required, check the parts against the accessory list. Follow the simple assembly instructions when connecting and make sure sure that the connection is secure.

4.Handle the product carefully during daily use, avoid Excessive pressing and impact to prevent damage to the product.

3. Precautions

1.Overloading is prohibited in order to avoid compromising the load-bearing capacity or the scope of application. Do not exceed the product's weight limit to avoid breakage and damage.

2.Minors are only allowed to use it under adult supervision, and Small accessories can be safely stored to prevent accidental ingestion. or to prevent loss.

3. Contact with corrosive liquids (e.g. B. Disinfectants, Vinegar,

Detergents, etc.) Avoid to prevent damage to the product surface.

4. Discontinue use of the product immediately if it is damaged or is loose, and do not use it forcefully to avoid safety hazards to cause.

4. Cleaning and Maintenance

1. For daily cleaning, wipe the surface with a dry cloth. or a slightly damp soft cloth to remove dust, and avoid Wash with water (except for waterproof models).

2. After cleaning, place it in a well-ventilated area. Let it dry. Do not expose it to direct sunlight or dry it. This is to prevent deformation and color fading of the material.

3. If it is not used for a long time, clean it and store it in a Dry and ventilated place, avoid pressing and piling.

Japanese

Instructions for use

1. Product name: Interior accessories

2. How to use

1. Take out the product and check whether its appearance is intact, and before use, check for any damage, deformation, or missing parts.

Please confirm that there is no missing item.

2. Please place the product in a stable and dry place according to its intended use. High temperature, high humidity Avoid the environment and sharp objects.

3. If assembly is required, check the parts based on the accessory list and complete the simple assembly. Follow the instructions to connect and make sure the connection is secure.

4. Please handle with care during daily use, avoid excessive pressure or impact, and protect the product. Please prevent damage.

3. Precautions

1. Overload use is prohibited. Do not exceed the product's load capacity or usage range, and avoid damage. Please prevent loss or damage.

2. Minors should use it under adult supervision. Please store small accessories properly and Please prevent accidental ingestion or loss.

3. Avoid contact with corrosive liquids (such as disinfectants, vinegar, detergents, etc.) to prevent damage to the product surface. Please.

4. If the product is damaged or loose, stop using it immediately and do not force it to continue use for safety reasons.

Please do not cause the above dangers.

4. Cleaning and maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth.

Please remove the dust. Avoid washing with water (except for waterproof models).

2. After cleaning, please dry it in a well-ventilated area. Exposed to direct sunlight

Please do not dry it. Prevents material deformation and fading.

3. If not used for a long time, after cleaning, store it in a dry and well-ventilated place.

Handle with care, do not press or stack.

Dutch

Instructions for use

1. Product Name: Household Goods

2. Gebruikswijze

1. Take the product out of the packaging, check whether the appearance is intact, and make sure ensure that there is no damage, deformation, or missing accessories before you used.

2. Place the product in a stable and dry place according to its intended use.

Avoid high temperatures, damp environments and sharp objects.

3. If assembly is required, please check the parts according to the accessory list. follow the simple assembly instructions when connecting and make sure that the connection is solid.

4. Handle the product with care during daily use, avoid excessive use. pressing and hitting to prevent damage to the product.

3. Voorzorgsmaatregelen

1. Overloading is prohibited in order to prevent the load-bearing capacity or scope of application of the Do not overfill the product to avoid breakage and damage.

2. Children under 18 years of age are only allowed under adult supervision. use, and small accessories should be kept in a safe place to prevent accidental loss. swallowing or losing.

3. Avoid contact with corrosive liquids (such as disinfectants, vinegar, etc.). washing powder etc.) to prevent damage to the surface of the product.

4. Immediately stop using the product if it is damaged or loose. and do not use it forcefully to avoid causing safety risks.

4. Cleaning and maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a

Slightly damp soft cloth to remove dust, and avoid washing with water.
(except for waterproof models).

2.After cleaning, place it in a ventilated place to dry.

Do not place it in direct sunlight or dry it to avoid deformation and discoloration of the item.
material to be avoided.

3.When not in use for a long time, clean it and store it in a dry and
ventilated place, avoid pressing and piling.

Finland

User manual

1. Product name: Home goods

2. Method of use

1.Take the product out, check if the exterior is intact and make sure there is no damage.
changes in form or missing parts before use.

2.Place the product on a stable and dry surface according to its intended use.
Avoid high temperatures, humid environments, and sharp objects.

3.If installation is necessary, check the parts based on the parts list, follow the instructions.
Simple installation instructions during the connection and make sure the connection is strong.

4.Handle the product carefully during daily use, avoiding excessive pressure.
and impacts to prevent damage to the product.

3. Huomautukset

1.Overloading is prohibited to prevent exceeding the product's load capacity or application range.
to prevent breakage and damage.

2.Children under the age of 18 may only use the product under adult supervision.
and small parts must be kept carefully to prevent accidental ingestion or
unfortunately.

3.Avoid contact with corrosive liquids (such as disinfectants, bleach, etc.).
pesuainetta jne.)with it to prevent damage to the product's surface.

4.Stop using the product immediately if it is damaged or loose, and do not use it.
forcedly to prevent security risks.

4. Cleaning and maintenance

1.For daily cleaning, wash the surface with fresh linen or gently.
wipe with a soft cloth to remove dust, avoiding water cleaning (except
sample models.

2.After cleaning, place it in a well-ventilated area to dry.
Do not place it directly in the sun or dry it to prevent damage to the material.
shape change and color fading.

3. When the product is not used for a long time, clean it and store it in a dry place.
in a good place for air circulation, avoiding pressure and stapling.

українська

Інструкція до БКПСТАHHIO

1. Назва продукту: Тобак н оми

2. Цілі БКПСТАHH

1. Бтарhib поyt, epeiпe, oii Brn he owoe, i
neпekcohatec B бincythocti nowkoehb, eopmai ta бincythix
komnnekTyloYnx neпe BKopncTahham.

2. Po3micTib npoyT y cTainbHomь ta cyxomy мici BiobiHo o oro
npn3Haehh, yhkaion bcokx Temneпatyp, Bonornx ceпeoB Ta roctpnx
nпeameTiB.

3. Akwo Heoxiho 3npahh, neпebipe etani 3a cнnckom komnnekTyionx,"
otпmyŭtecб npoctx iHcTpyi 3 3pahh ni ac 3'ehahh ta neпeoHatec
B Miyhocti 3'enHahHa.

4. No one can explain it to me, because I have 3 questions.
The Hamiphoro cтncky is being made, and the 3-year-old child is now learning to walk.

3. Засте́пexеHH

1. 3aopoetbc neпeahtaeh, o he neпeBwyatn
BahtaxoniqomHictb ao qiana3oH 3actocyBahh npoykty, 3anoiraion po3pnBy.
Ta nOWKOKeHHIO.

2. Heoпocни aiob kopncTyatnc npoykтом nnwe ni harnaom oпocnnx, a
The number of connections is 3 ports, and there are 3 lines.
BNnaKOBOMь npOKOBTyBaHHIO ao BTpaTi.

3. yhnkae koHtatь 3 kopo3ihmn pinhamn (hanpkna, e3iiкyioi 3acon,
oet, oom n ai mo), o ai koei ephi поytь.

4. Herao ae Bca yy, ao Bi or a
po3ipa, i he oпncyŭec hm npmycoBo, o he Bknнан hee3nen n
be3nekn.

4. ОнмehH Ta орна

1. Ang moehhoro nmehh нотpae oBepxhio cyxoio TaHhoo ao
3nera Bonoro m'akoo taoio, mo pпан nn, ya m Bool
(kpim BoohenpohnkhnX Monene).

2. The original picture has been compressed and the image quality is poor. He
Bbictabнаŭte ha npami cohahi npomehi ao cywitb, mo 3anoirтn eopmai
mateпiany Ta 3Heapbnehhio.

3. pn tпnBanomy heBKopncToBybahhi oynctiTb ta 3epirate y cyxomy Ta

np0BitpeHomy micui, yHnkaioyn cTncky Ta ctonkn.

Eesti

Kasutusjuhend

1  Product name: Household items

2 Kasutusviis

1. Check the product carefully, see if the outer box is empty, and make sure before proceeding.

There are no scratches, deformations, or missing parts on the shoes.

2. Place the product on a stable and dry surface according to its intended use.

Avoid high temperatures, humid environment and sharp objects.

3. If you need a few, check out the partial guide below, follow the simple instructions for assembly.

Make sure the connection is secure and stable.

4. Handle the product carefully during daily use, avoiding excessive pressure and you did not prevent the product from being damaged.

3. Marks

1. Excessive load is prohibited, so as not to exceed the product's carrying capacity or application area. prevent breakage and damage.

2. All products intended for use on 18-year-olds are intended for adult supervision only, and Small parts must be handled properly to prevent accidental leakage or loss.

3. Avoid contact with corrosive liquids (e.g., disinfectants, ethanol, etc.). pesuaine etc.), and to prevent the product from being damaged.

4. Stop using the product immediately if it is damaged or leaking, and do not Use it in such a way as to avoid harming the fragile parts.

4. Cleaning and maintenance

1. For daily cleaning, wash the pan with a dry cloth and wipe lightly with a slightly damp cloth. With a rag, you don't remove the dirt, avoiding waterlogging (except for water-resistant varieties). mudelid.

2. After cleaning, place it in a well-ventilated area to dry. Ärfe

Do not expose it to direct sunlight or dry it, to prevent the material from deforming and color adjustment.

3. If the product is not used for a long time, clean it and keep it dry and ventilation in a proper place, avoiding crowding and overlapping.

Spanish

Instruction Manual

1  Product name: Household items

2 How to use

1. Remove the product, check that the appearance is intact and make sure that Ensure there is no damage, deformation, or missing accessories before use.
2. Place the product in a stable and dry location according to its intended use, avoiding high temperatures, humid environments, and sharp objects.
3. If assembly is required, check the parts according to the accessory list. Follow the simple assembly instructions when joining and make sure that the connection is firm.
4. Handle with care during daily use to avoid compression and impact. excessive, preventing damage to the product.

3 Precautions

1. Overloading is prohibited to avoid exceeding the load capacity or range of application of the product, preventing breakage and damage.
2. Minors must use the product under the supervision of adults, and Small accessories should be stored properly to prevent damage. Accidental ingestion or loss.
3. Avoid contact with corrosive liquids (such as disinfectants, vinegar, etc.). laundry detergent, etc.) to prevent damage to the product's surface.
4. Stop using the product immediately if it is damaged or loose, and do not use it for the force so as not to cause safety risks.

4. Cleaning and maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a soft cloth. slightly damp to remove dust, avoiding cleaning with water (except waterproof models).
2. After cleaning, place it in a ventilated place to dry. No lo Do not expose it to direct sunlight or dry it to prevent material deformation and the discoloration.
3. When not in use for a long time, clean it and store it in a dry place. and ventilated, avoiding compression and stacking.

Svenska

User Manual

1 Produktnamn: Hushållsartiklar

2 Modes of use

1. Take out the product, check that the appearance is intact and make sure there are no defects. any damage, deformations, or missing accessories before use.
2. Place the product on a stable and dry shelf according to its intended purpose, avoiding high temperatures.

temperatures, humid environments, and sharp objects.

3.If assembly is required, check the parts according to the accessory list, follow the simple instructions.
Follow the assembly instructions when connecting and ensure that the connection is stable.

4.Handle the product carefully during daily use, avoid excessive pressure.
and supports to prevent damage to the product.

3 ⚠ Varningar

1.Overloading is prohibited in order not to exceed the product's load capacity or area of application, to prevent crime and injury.

2.Young people under 18 years of age may only use the product under supervision of adults, and small accessories must be stored properly to prevent accidental ingestion or loss.

3.Avoid contact with corrosive liquids (such as disinfectants, corrosives, detergent etc.) to prevent damage to the product's surface.

4.Stop using the product immediately if it is damaged or loose, and use not necessarily to cause security risks.

4. Cleaning and maintenance

1.For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth.
To remove dust, avoid washing with water (except for models that are water-resistant).

2.After cleaning, place it in a ventilated area to dry.Do not place it in
Avoid direct sunlight or knock it to prevent deformation and fading of the material.

3.When not in use for a long period of time, clean and store it in a dry and ventilated stable, avoid pressure and crowding.

Danish

Betjeningsvejledning

1 ⚠ Produktnavn: Husholdningsartikler

2 ⚠ Brugsmåde

1.Take out the product, check if the appearance is intact and make sure there are no damage, deformities, or missing accessories before it is used.

2.Place the product in a stable and dry place according to its intended purpose, avoiding high temperatures.
temperatures, humid environments, and sharp objects.

3.If assembly is required, please check the parts according to the accessory list, follow the simple monteringsanvisninger ved tilslutning og sørg for, at forbindelsen er solid.

4.Handle the product carefully during daily use, avoiding excessive pressure and impact.
to prevent damage to the product.

3 ⚠ Reserves

1.Overloading is prohibited in order not to exceed the product's load capacity or anvendelsesområde, for at forhindre brud og skade.

2.Young people under 18 years old should only use the product under adult supervision, and Small accessories should be stored properly to prevent accidental ingestion or loss.

3.Avoid contact with corrosive substances (such as disinfectants, acids, vaskemiddel etc.)for at forhindre skade på produktets overflade.

4.Please stop using the product immediately if it is damaged or loose, and use it not necessarily to cause security risks.

4. Cleaning and maintenance

1.For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth. To remove dust, avoid washing with water (except for waterproof models).

2.After cleaning, place it in a ventilated area for drying.Please don't place it directly Sollys dries it to prevent deformation and fading of the material.

3.When not in use for a long time, clean it and store it in a dry and ventilated place. avoid pressure and stacking.

Romana

Instruction Manual

1|||Product Name: Household Items

2|||Mode of use

1.Remove the product, check if the appearance is intact and make sure that it is not damaged. there is damage, deformation, or missing accessories before use.

2.Place the product in a stable and dry place according to its intended purpose, avoiding high temperatures, humid environments, and sharp objects.

3.If assembly is necessary, check the parts according to the accessories list. Follow the simple assembly instructions upon connection and ensure the connection is secure. It is solid.

4.Manevrati cu grija în timpul utilizării zilnice, evitând compresia și impactul excesive, to prevent damage to the product.

3|||Preventii

1.It is forbidden to overload in order not to exceed the carrying capacity or field of application of the product, to prevent breakage and damage.

2.Minors must use the product in question under the supervision of an adult. adults, and small accessories should be properly stored to prevent ingestion accidental or loss.

3.Avoid contact with corrosive liquids (such as disinfectants, alcohol, detergent). of calls etc.) to prevent damage to the product's surface.

4. Immediately stop using the product if it is damaged or loose, and do not use it. Use it wisely to avoid creating risks for safety.

4. Curatare si intretinere

1. For daily cleaning, wipe the surface with a dry napkin or cloth. soft, easily moistened to remove dust, avoiding washing with water (excepting Waterproof models.

2. After cleaning, place it in a ventilated place to dry. Do not expose it to sun directly or not dry it to prevent the material from deforming and discoloring.

3. When not in use for a long time, clean it and store it in a dry place and ventilated, avoiding compression and constriction.

Norwegian

Bruksanvisning

1. Produktnavn: Husholdningsartikler

2. Bruksmate

1. Take out the product, check if the appearance is intact and make sure there are no damages. deformities or missing accessories before use.

2. Place the product in a stable and dry place according to its intended purpose, avoiding high temperatures. temperatures, wet environments, and sharp objects.

3. If assembly is required, please check the parts against the accessory list, follow the simple the installation instructions when connecting and make sure the connection is stable.

4. Handle the product carefully during daily use, avoid excessive pressure and impact. to prevent damage to the product.

3. Warnings

1. Overloading is prohibited in order not to exceed the product's load capacity or anvendelsesområde, for å forhindre brudd og skade.

2. Young people under 18 years old should only use the product under adult supervision, and small accessories must be stored properly to prevent accidental ingestion of poison.

3. Avoid contact with corrosive liquids (such as disinfectants, vinegar, vaskemiddel etc.) to prevent damage to the product's surface.

4. Stop using the product immediately if it is damaged or loose, and use it not necessarily to cause security risks.

4. Cleaning and maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a slightly damp soft cloth. To remove dust, avoid washing with water (except for waterproof models).

2. After cleaning, place it in a ventilated area to dry. Do not put it in

Dry it directly in the sun or use a dryer to prevent deformation and fading of the material.

3. When not in use for a long time, clean and store it in a dry and ventilated place.
unngå trykk og stablling.

Latviešu

Lietošanas rokasgrāmata

1. Product name: Majoklu preces

2. Current methods

1. Use the product, check it, or the appearance will remain unchanged, and make sure that...
Before use, check for any damage, deformation, or missing accessories.

2. Store the product in a stable and dry place according to its instructions, avoid
high temperatures, with empty shelves and empty objects.

3. No assembly is required, please check the details against the accessory list.
follow the simple assembly instructions by connecting and make sure that
The connection is solid.

4. When using it daily, handle the product with care and avoid excessive use.
ironing and blowing to prevent product damage.

3. Warnings

1. It is prohibited to overcharge in order not to compromise the product's cutting power or
the usage range, eliminating fraying and staining.

2. The product is not effective for the treatment of growing acne, and it is small.
Accessories must be stored properly to prevent accidental crushing or loss.

3. Avoid contact with corrosive substances (e.g., disinfectants,
ocetam, tīrīšanas līdzekļiem utt.), lai novērstu produkta virsmas bojāšanu.

4. I tried using the product, but it is either damaged or has malfunctioned, and it doesn't work.
Please do not take security risks lightly.

4. Cleaning and maintenance

1. For daily cleaning, spray the surface with a dry cloth or a small amount of water.
Use a soft cloth to wipe the dust, avoid cleaning with water (except
without rigid models.

2. After cleaning, place the product in a ventilated area to dry. Nemejiet to
Exhibit directly in sunlight or dry to prevent material deformation and color changes.
disappointed.

3. The product has been used for a long time, clean it and store it in a dry and ventilated place.
Avoid haste and carelessness.

French

User Manual

1. Product Name: Household Goods

2. Instructions for use

1.Remove the product, check that its appearance is intact, and make sure that it
There are no damages, deformations, or missing accessories in front.
use.

2.Place the product in a stable and dry place according to its usage, avoiding the
high temperatures, humid environments, and sharp objects.

3.If assembly is required, check the parts according to the accessories list.
follow the simple assembly instructions for connection and make sure
that the connection is solid.

4.Handle with care during daily use to avoid any damage.
compression and excessive shocks, preventing damage to the product.

3. Précautions

1.Overloading is prohibited to avoid exceeding the load capacity or the
range of product application, preventing breakage and damage.

2.Minors must use the product under the supervision of adults, and children
Accessories should be stored properly to prevent accidental ingestion or damage.
losses.

3.Avoid contact with corrosive liquids (such as disinfectants,
vinegar, laundry detergent, etc.)to prevent damage to the surface of the
product.

4.Immediately stop using the product if it is damaged or loose, and do not
Do not use it forcefully to avoid causing safety risks.

4. Cleaning and maintenance

1.For daily cleaning, wipe the surface with a dry cloth or a
Soft, slightly damp cloth to remove dust, avoiding direct cleaning.
water (except for waterproof models).

2.After cleaning, place it in a ventilated place to dry.Do not expose it
Do not expose to direct sunlight or dry it to prevent deformation of the
material and discoloration.

3.When not in use for a long time, clean it and store it in
a dry and ventilated place, avoiding compression and stacking.

Português

Instruction Manual

1. Product Name: Household Goods

2. How to Use

1. Remove the product, check if the appearance is intact, and confirm that there are no damage, deformation, or missing accessories before use.

2. Place the product in a stable and dry location according to its intended purpose. Avoiding high temperatures, humid environments, and sharp objects.

3. If assembly is required, check the parts according to the list of accessories, follow the simple assembly instructions for the joint and make sure to that the connection is firm.

4. Handle with care during daily use to avoid compression and impact. excessive, preventing damage to the product.

3. Precauções

1. Overloading is prohibited to avoid exceeding the load capacity or the allowable range. of product application, preventing breakage and damage.

2. Minors must use the product under adult supervision, and the Small accessories should be stored properly to prevent ingestion. accidental or loss.

3. Avoid contact with corrosive liquids (such as disinfectants, vinegar, detergent). for clothing, etc.) to prevent damage to the product's surface.

4. Immediately stop using the product if it is damaged or loose, and Do not use it forcefully to avoid causing safety risks.

4. Cleaning and Maintenance

1. For daily cleaning, wipe the surface with a dry cloth or a soft cloth. slightly damp to remove dust, avoiding cleaning with water (except waterproof models).

2. After cleaning, place it in a ventilated place to dry. Do not expose to light Do not dry the solar panel directly to prevent material deformation and fading.

3. When not in use for a long time, clean it and store it in a dry and Airy, avoiding compression and piling.

Italiano

Instruction Manual

1. Product Name: Household Goods

2. Mode of Use

1. Take out the product, check that the appearance is intact and confirm that there are no defects. Check for any damage, deformation, or missing accessories before use.

2.Place the product in a stable and dry location according to its intended use.

Avoid high temperatures, humid environments, and sharp objects.

3.Assembly is required, please check the parts according to the parts list. accessories, follow the simple assembly instructions for the connection and make sure that the connection is solid.

4.Handle with care during daily use to avoid compression and impact. excessive, preventing damage to the product.

3. Precautions

1.Overload is prohibited to avoid exceeding the load capacity or the range of application of the product, preventing breakage and damage.

2.Minors must use the product under the supervision of adults, and the accessories Small items should be properly stored to prevent ingestion. accidental or loss.

3.Avoid contact with corrosive liquids (such as disinfectants, vinegar, detergent for the hole, etc.)to prevent damage to the product's surface.

4.Immediately stop using the product if it is damaged or loose, and Do not necessarily use it to avoid causing safety risks.

4. Cleaning and Maintenance

1.For daily cleaning, wipe the surface with a dry cloth or cloth. Soft, slightly damp to remove dust, avoiding washing with water. (except waterproof models).

2.After cleaning, place it in a ventilated place to dry.Do not expose it in direct sunlight or dry it to prevent material deformation and the fading.

3.When not in use for a long time, clean it and store it in a place Dry and ventilated, avoiding compression and stacking.