

Product Manual of Arts & Crafts

Quick Start Guide:

- Plug in the USB cable to charge the 3D pen.
- Select the desired filament type and insert it into the pen.
- Adjust the temperature and speed settings using the digital display.
- Start creating your 3D objects or doodles.

Warnings:

- CHOKING HAZARD - Small parts. Not for children under 3 yrs.
- Ensure the pen is turned off when not in use to prevent overheating.

Safety Information:

- Keep the pen dry and avoid exposure to moisture.
- Wipe the pen with a damp cloth for cleaning.
- Store the pen in a cool, dry place when not in use.

Service: Contact our store support for any issues.