General Lighter Instruction Manual (Simplified English Version)

Important Safety Warnings (Must Read First)

- **FLAMMABLE & PRESSURIZED CONTENTS**: Contains flammable gas under pressure; risk of fire, explosion or burns if misused.
- **KEEP AWAY FROM CHILDREN**: Not a toy — store in a secure place out of reach of kids and pets at all times.
- **NO HIGH TEMPERATURE**: Do not expose to heat, open flame, direct sunlight or temperatures above 45°C (113°F); do not leave in a hot car.
- **DO NOT ABUSE**: Do not puncture, drop, crush, disassemble or throw into fire. Do not ignite continuously for more than 30 seconds.
- **NO FLAMMABLE AREAS**: Prohibited for use at gas stations, fuel depots, chemical plants or any explosive/flammable environments.
- **SAFE IGNITION**: Keep face, hands, clothing and all flammable objects away from the flame tip when lighting.

Intended Use

For adult use only as a portable ignition tool for cigarettes, candles, paper and similar small items. Not for any other purpose.

Basic Operation

1. Hold the lighter firmly with the flame nozzle pointing away from your body.
2. Press the ignition button/slide the flint wheel to light the flame.
3. Adjust flame height (if adjustable): Turn the regulator knob clockwise to lower, counterclockwise to raise. Do not over-adjust.
4. Release the button to extinguish the flame completely after use.

Refueling (For Refillable Lighters Only)

- Use only **pure butane fuel**; low-quality fuel may damage the lighter.
- Refill in a well-ventilated area, away from any sparks or flames.

- Invert the lighter, press the butane canister nozzle firmly into the refill valve for 2–3 seconds. Repeat if needed.
- Wait 1–2 minutes before igniting to allow gas to stabilize and excess fuel to evaporate.

Troubleshooting (Simple Fixes)

- **Will not light**: Check fuel level, clear nozzle blockage, replace flint (for flint lighters).
- **Weak flame**: Refill fuel or adjust flame height.
- **Gas leak/odd smell**: Stop use immediately — do not ignite. Dispose of safely.

Storage & Disposal

- Store in a cool, dry, ventilated place away from heat and fire sources.
- Disposal: Fully release remaining gas before discarding. Do not burn or puncture the empty lighter.

Disclaimer

The manufacturer is not liable for injury, fire or damage caused by improper use, abuse, tampering or failure to follow these safety instructions.

（注：文档部分内容可能由 AI 生成）