
MCHOSE




— A5 V3 Gaming —


WIRELESS MOUSE

Kind Reminder: The images in this manual are for illustration purposes only. Please refer to the actual product.

PRODUCT OVERVIEW




CHARGING / WIRED CONNECTION



● Insert the included Type-C end of the USB cable into the mouse and the USB-A end into your computer to start using it.

● Once the USB cable is connected, the mouse switches to wired mode and charges at the same time.


2.4G CONNECTION



● Connection Method 1 (Recommended): Connect the included cable to your computer's USB 2.0/3.0 port①, insert the cable's Type-C end into the adapter's Type-C port②, and plug the receiver③ into the adapter's Type-A port. After inserting the receiver, place the adapter on the desktop and keep the distance between the receiver and the mouse within 30 cm.

● Connection Method 2: Plug the receiver③ directly into your computer's USB 2.0/3.0 port①.

WIRELESS CONNECTION



● Switch the mouse to Position "B", then search for and connect to the device named "MCHOSE A5 V3".

● If pairing fails, press and hold the Left + Middle + Right buttons for about 5 seconds until the indicator light flashes rapidly to enter pairing mode, then try connecting again. The indicator will turn off once the connection is successful.

DRIVER INTRODUCTION

Web Driver

https://www.mchose.store/pages/firmware-2

Open the URL in a browser, click on **[Open M HUB WEB]** > **[Initialize Device]** > **[Allow Browser Access]**, and then select the corresponding product model to connect.


Desktop App Driver

https://www.mchose.store/pages/firmware-2

Open the URL in a browser, click on **Download M HUB Driver** and then download and install it.

Note: The MHUB desktop app driver currently supports only Windows 10 and above; Windows 7 and macOS are not supported at this time.

DPI ADJUSTMENT



BATTERY STATUS INDICATOR



● Indicator light flashing red: Please charge promptly.

● Red light steady on: Charging in progress.

● Green light steady on: Charging complete.

NOTICE

This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This device generates, uses, and can radiate radio frequency energy, and if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device on and off), we encourage the user to try one or more of the following measures to correct the interference:

● Reorient or relocate the receiving antenna.
● Increase the distance between the device and receiver.
● Connect the device to a different circuit from the one to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.
The operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via the computer's USB port.
2. Do not use fast-charging phone chargers to charge the mouse.
3. Do not use low-quality, non-standard power adapters to charge the mouse.
4. Do not use over-voltage or over-current power adapters to charge the mouse.
5. Keep the mouse away from high-temperature devices during charging.
6. Turn off the power switch when the mouse is not in use for an extended period.

The above charging instructions also apply to other rechargeable devices (keyboard, mouse, headset, speakers, etc.).