

User Manual for Lenovo Xiaoxin Pad Pro GT TB710FU

1. Product Overview

Brand: Lenovo

Model: TB710FU (Xiaoxin Pad Pro GT)

Version: 8GB RAM + 256GB ROM, WIFI Only

Color: Light Sea Shell

Product Type: Tablet PC

Screen: 11.1-inch LCD, 3200×2000 Resolution, 800nits Brightness, 144Hz Refresh Rate, TÜV Rheinland Global Eye Protection 3.0 Certification, Corning Gorilla GG7i Glass

Processor: Qualcomm Snapdragon 8 Gen 3

Storage: LPDDR5X RAM + UFS 4.0 ROM

Battery: 8860mAh, Support 68W Fast Charging

Core Functions: Tianxi Personal Super Intelligent Agent (AI Search/Translation/Notes), 4 Speakers with Dolby Atmos, WIFI 6, Full-Function USB-C Port, Face Recognition Unlock

Appearance: All-Metal Body, 458g Weight, 5.99mm Thickness

2. Important Safety Information (Warning!)

Read all guidelines carefully to avoid electric shock, device damage and personal injury. Improper use may cause severe hazards.

2.1 Electric Shock & Water Hazard

- Do not use the tablet near water or in wet environments to avoid electric shock.
- Never immerse the tablet, charger or data cable in water, or pour water on the device.
- Unplug the charger before cleaning; do not touch the charger or charging port with wet hands.
- Use only original Lenovo chargers and data cables to prevent short circuits or overheating.

2.2 Device & Personal Safety

- Do not drop, bend, squeeze or pierce the tablet. The screen may shatter if impacted.
- Keep away from high temperatures (direct sunlight, stoves) and flammable materials to prevent battery damage or fire.
- The tablet may get slightly warm during charging/heavy use (normal); stop using if it overheats.
- Do not disassemble or modify the tablet; internal components are not user-serviceable.

2.3 Usage by Children & Vulnerable People

- Children under 3 must be supervised near the tablet to avoid accidental injury or screen damage.
- Children aged 8+ can use it under adult guidance; no unsupervised disassembly, charging or cleaning.
- Avoid prolonged use by children; enable Eye Protection Mode to protect eyesight.

2.4 Other Safety Warnings

- Do not place heavy objects on the tablet to avoid structural damage.
- Stop using immediately if the tablet is dropped/damaged; contact the AliExpress seller for support.
- Do not use in extreme environments (too cold/humid) to avoid functional failure.

3. How to Use

3.1 Before Use

- Unbox and check if the tablet, charger and data cable are intact.
- Charge fully before first use (about 30 minutes to 50% with 68W charger).
- Turn on and follow the on-screen guide to complete initial setup (language, WIFI, account).

3.2 Basic Operation

- Power On/Off: Press and hold the Power Button for 3 seconds to turn on/off.
- Screen Lock/Unlock: Press the Power Button to lock; unlock via face recognition or password.

- **WIFI Connection:** Go to Settings > WIFI, select your network and enter the password.
- **AI Functions:** Call Tianxi Intelligent Agent for AI search, translation and note-taking (follow on-screen prompts).
- **Fast Charging:** Use the original 68W charger for quick charging; avoid charging with unqualified chargers.

4. Maintenance and Cleaning

4.1 Maintenance

- Charge the battery to 50% before long-term storage; avoid long-term idle.
- Update the system via Settings > System Update for better performance.
- Do not install untrusted apps to protect device security and privacy.

4.2 Cleaning

- Unplug the charger before cleaning; wipe the screen and body with a soft, dry cloth.
- Do not use abrasive cleaners or flammable solvents to avoid damaging the all-metal body.
- Clean the charging port with a dry cotton swab regularly to remove dust.

5. Compliance Information (For EU Market)

This product complies with EU Low Voltage Directive (LVD) 2014/35/EU and Electromagnetic Compatibility Directive (EMC) 2014/30/EU.

CE Marking: This product bears the CE mark, signifying compliance with all applicable EU directives.

Authorized Representative (EU): [Please enter your EU authorized representative information here]

6. Disposal Instructions

- Unplug and turn off the tablet completely before disposal or maintenance.

Do not dispose of this product with household waste. Dispose of it in accordance with local WEEE regulations to protect the environment.

7. Notes

- Store in a dry, clean environment when not in use; do not place heavy objects on it.
- Contact the AliExpress seller for assistance if the tablet malfunctions (do not disassemble it yourself).
- Slight operation noise is normal and does not indicate a malfunction.
- Product specifications and appearance are subject to change without prior notice; actual product shall prevail.
- For indoor use only; avoid harsh outdoor environments.