TWS Bluetooth Earbuds User Manual

1. Product Introduction

- Type: TWS True Wireless Bluetooth Earbuds (with charging case)
- Bluetooth version: 5.0+
- Effective distance: Approx. 10 meters
- Charging port: Type-C
- Battery life: Single use approx. 3–5 hours; charging case provides 2–3 extra charges

2. Preparation for First Use

1. Take out the earbuds and remove the insulating film on the charging contacts.

2. Place earbuds into the charging case, close the lid, and charge for 10 minutes to activate the battery.

3. Choose the appropriate ear tips for a stable and comfortable fit.

3. Bluetooth Pairing (Mobile Phone / Tablet)

Method A: Auto Pairing (Recommended)

1. Go to your device Settings → Bluetooth, and turn Bluetooth on.

2. Open the charging case; the earbuds power on and enter pairing mode automatically (LED flashes red and blue quickly or voice prompt "Pairing").

3. Select the earbuds name (e.g., AirBuds Pro, TWS-X1) in the Bluetooth list.

4. Connected successfully: LED changes to slow flash or off, device shows "Connected".

Method B: Manual Pairing

For re-pairing with a new device:

1. Place earbuds in the case and keep the lid open.

2. Press and hold the function button on the case for 5 seconds until the LED flashes red and blue quickly.

3. Search and connect on your device.

Default PIN code (if required):
0000 or 1234

4. Basic Controls (Touch / Button)

Playback & Call Controls

- Play / Pause: Single tap the touch area
- Previous track: Triple tap left earbud or long press left for 2 seconds
- Next track: Triple tap right earbud or long press right for 2 seconds
- Answer / End call: Single tap
- Reject call: Long press for 2 seconds
- Activate voice assistant (Siri / Xiao Ai / Duero): Long press for 3 seconds

Volume Control

- Volume +: Double tap right earbud or long press right
- Volume -: Double tap left earbud or long press left

Power On / Off

- Power on: Open the charging case
- Power off: Place earbuds into the case and close the lid

5. Charging Instructions

Earbuds Charging

1. Place earbuds into the case with charging contacts aligned.

2. Charging: Earbud LED stays on.

3. Fully charged: LED turns off (approx. 1 hour).

Charging Case Charging

1. Connect the case to a charger or USB port with a Type- C cable.

2. Charging: Case LED flashes.

3. Fully charged: LED stays on or turns off (approx. 1.5 hours).

6. Troubleshooting

1. Cannot find the earbuds

- Make sure the earbuds are in pairing mode (red & blue fast flash)
- Turn Bluetooth off and on again
- Reset: Place earbuds in case, long press function button for 10 seconds

2. No sound or only one side works

- Check device volume and Bluetooth audio output
- Place both earbuds back into the case, close and reopen to re-pair
- Clean the charging contacts

3. Disconnects automatically

- Keep within 10 meters and avoid obstacles
- Charge the earbuds if low battery
- Restart Bluetooth on your device

7. Notes

- Avoid water, dropping, and high temperatures.
- Clean ear tips and earbuds regularly for hygiene.
- If not used for a long time: Charge to 50% and store in the case.