

Handheld Vegetable Grater Instructions

1. Press the food against the grater blade and scrape evenly to shred.
2. The blade is sharp. Wear protective gloves to avoid cuts.
3. Do not grate hard ingredients (e.g., frozen meat, bones) to prevent blade damage.
4. Rinse with water after use, wipe dry and store in a dry place.
5. Do not drop or strike violently to avoid deformation.
6. Keep away from children to prevent injury.